

DETECTION DES MACLES DANS LE YAB = $\text{YAl}_3(\text{BO}_3)_4$

PAR MESURE DU POUVOIR ROTATOIRE

Sebastian Schwung, Andreas Groß, Christoph
Liebald, Volker Wesemann, **Daniel Rytz**

***EOT GmbH**, Struthstrasse 2, 55743 Idar-Oberstein,
Allemagne*



Twins in YAB

Outline:

Why YAB?

- NLO crystals for UV

- Issues with twins (scattering, multiple beams)

Twinned crystals

- Appearance and properties




Detection based on optical rotation

Outlook: other interesting properties of YAB

The logo for Electro-Optics Technology GmbH, featuring the letters 'EOT' in a stylized, red, italicized font.

Electro-Optics Technology GmbH


NLO CRYSTALS FOR UV (250-270 nm)



EOT

Electro-Optics Technology GmbH

MATERIALS FOR SHG 266 nm



| | Type I phase matching angle (°) | d_{eff} (pm/V) | Angular acceptance (mrad cm) | Temperature-acceptance (°C cm) | Walk-off (°) |
|---|---------------------------------|-------------------------|------------------------------|--------------------------------|--------------|
| BBO BaB_2O_4 | 47.5 | 1.1 | 0.17 | 5 | 4.8 |
| CLBO $\text{CsLiB}_6\text{O}_{10}$ | 61.5 | 0.8 | 0.49 | 6.2 | 1.9 |
| LTB $\text{Li}_2\text{B}_4\text{O}_7$ | 66,5 | 0,16 | 0,49 | > 21 | 1,6 |
| YAB $\text{YAl}_3(\text{BO}_3)_4$ | 66.2 | 0.69 | 0.41 | 6 | 1.9 |

Advantages of YAB:



Mechanical stability

Hardness

High damage threshold

Twins in YAB crystals: scattering effects

In collaboration with A. Maillard, Univ. of Metz (France), Jan. 2011



Laser beam (at 532 nm) propagates along z axis.

Strong scattering observed along all three X = a directions.

EOT

Electro-Optics Technology GmbH

Angular acceptance in YAB crystals

Comparison between twinned and twin-free volume




Fig. 2. Angular acceptance curves for phase matched Yb:YAB in crystals without (a) and with (b) twinning. In both cases ϕ was orientated normal to the probe beam.



P. Decker and J.M. Dawes, „Characterization of nonlinear conversion and crystal quality in Nd- and Yb-doped YAB“, Optics Express, 5922, 12 (2004).

EOT


Electro-Optics Technology GmbH

YAB growth TSSG with Li_2WO_4 flux

L22-1, weight = 22.7 g




C303-2, weight = 9.2 g






YAB = $\text{YAl}_3(\text{BO}_3)_4$ grown by TSSG

Li_2WO_4 flux, 70 ml platinum crucible, in air.
Cooling range 25°C.
Duration 25 days.
Boule weight up to 40 grams.



„Microstructures“ observed in YAB crystals

C-DIC = Circular Polarized Light Differential Interference Contrast Microscopy.



Both samples observed along X.

Typical width of lamellas between 5 and 200 μm.

Angle between lamellas is 109°.

See also:

M. Bourezzou, A. Maillard et al., Opt. Mat. Exp. 1 (2011) 1570 .



P. Dekker and J. Dawes, Appl. Phys. B 83 (2006) 267.

EOT

Electro-Optics Technology GmbH


Twins in other crystals

Example: BaTiO₃
at 22 °C




Other type of microstructures


Example: KTaO_3
(Shadograph)



Growth striae,
reflecting positions of
growth interface.



C-DIC micrograph of YAB plate




EOT


Electro-Optics Technology GmbH

Twins in YAB crystals

TB 0194 (02)



TB 0195(03)



TI 0184(01)



Axis:
 $(90^\circ - \theta_{PM})X \rightarrow Z$


EOT

Electro-Optics Technology GmbH

Twins in YAB crystals

revealed by changes in optical activity


Sample viewed along Z axis between slightly misadjusted crossed polarizers




J. Buchen , V. Wesemann , S. Dehmelt , A. Gross , D. Rytz,
Crystals 2019, 9(1), 8; <https://doi.org/10.3390/cryst9010008>.

Measurement of optical rotatory power

In spectrophotometer:




With laser source:



L: light source
M: monochromator
P: rotatable polarizer
C: crystal
A: rotatable analyzer:
D: detector


Transmittance as a function of pol. angle



PA: measured through polarizer and analyzer

PCA: through polarizer, crystal and analyzer

Optical rotatory power in α -quartz



T.M. Lowry, Optical Rotatory Power, Longmans, London, UK, 1935.

V. Devarajan and A.M. Glazer, Acta Cryst. A 42 (1986) 560.

EOT

Electro-Optics Technology GmbH

Optical rotation angles in YAB („single domain“ case)





Figure 3. Optical rotation angles of YAB measured on domains with different optical path lengths. In (a), the lines show the result of simultaneously fitting a dispersion relation to the observed rotation angles at all wavelengths and path lengths shown in (a). The red line in (b) shows the fitting result of (a) for a wavelength of 632.8 nm. The shading indicates propagated uncertainties on fitted parameters. Note the linear relation between observed rotation angles and path lengths in (a) and the agreement of the fit with measurements at 632.8 nm on very thin domains in (b).


EOT

Electro-Optics Technology GmbH

Optical rotation angles in YAB (multiple domains)






Optical rotation angles in YAB (multiple domains)



EOT

Electro-Optics Technology GmbH
(FEE-U. Mainz, 2013)

Complete sign change of optical rotation in YAB (and KABO)



Images obtained with slightly decrossed polarizers, with two different positions at approx. 90° .

Note congruence between dark (extincted) and bright domains.


Rings indicate position for measurement (laser beam).

Color of rings change with sign of rotatory power.

EOT

Electro-Optics Technology GmbH

Optical rotatory power for different wavelengths



| | 266 nm | 532 nm | 633 nm |
|------|------------|--------|----------|
| YAB | 29-30 °/mm | 5 °/mm | 3,5 °/mm |
| KABO | | 3 °/mm | 2,1 °/mm |

Optical rotatory power: a comparison

| Crystal | Dispersion Relation ^a | | |
|--|----------------------------------|------------------|--------------------------------------|
| | A (° mm) | λ_1 (nm) | ρ_{633}^b (° mm ⁻¹) |
| Low-quartz, α -SiO ₂ | 7.17(3) | 129(1) | 18.69(9) |
| YAB, YAl ₃ (BO ₃) ₄ | 1.32(2) | 149(4) | 3.50(6) |
| KABO, K ₂ Al ₂ B ₂ O ₇ | 0.80(1) | 148(3) | 2.10(3) |


^a $\rho = A / (\lambda^2 - \lambda_1^2)$; ^b rotatory power at $\lambda = 632.8$ nm.

EOT

Electro-Optics Technology GmbH

Twinning in α -quartz crystals

Lamellas in quartz with
Brazil-type twins.




*Graphs from R. Rykart
„Quartz-Monographie“
(Ott Verlag, Thun, 1995)*

*Micrograph from A. Maillard,
YAB crystal from FEE
(Univ. de Metz, 2009)
Scale bar = 100 μm*

EOT

Electro-Optics Technology GmbH



Summary and outlook



Twins in YAB are common and appear for doped and undoped crystals independently of the flux used in the growth process.

Eliminating twins is important for applications of YAB as a frequency converter.

Twins can be best analyzed by measuring the **optical activity**. A criterion has been found to determine if a crystal is twin-free.

(RE)AB crystals are also potentially interesting for:

- short pulse lasers;
- eye-safe sources;
- fluorescence standards.



EOT

Electro-Optics Technology GmbH

Acknowledgment

J. Buchen, S. Haab, K. Dupré, A. Gross, C. Liebald, M. Peltz,
S. Schwung, V. Wesemann, B. Nelson (EOT)
T. Jüstel, F. Baur, P. Pues (FH Münster)
C. Rothardt (IOF, Jena)
Ph. Veber (ILM, Lyon)
M. Velázquez (SIMAP, Grenoble)
P. Loiseau, G. Aka, F. Cassouret, B. Viana (ENSCP, Paris)
A. Maillard, R. Maillard (LMOPS, Metz)
C. Guguschev, M. Schulze, M. Bickermann (IKZ Berlin)
T. Trendle, F. Kühnemann (IPM, Freiburg)

DUVEL (2016 – 2019, sponsored by BMBF).

IsoNova (2017 – 2020, BMBF).

LUKS (2018 – 2021, BMBF).

BINGO (2019 – 2022, BMBF).

PYKKO (2020 – 2022, AIF).

Thank you for your attention

Gefördert von / Sponsored by



Bundesministerium
für Bildung
und Forschung



EOT

Electro-Optics Technology GmbH